



Thank you for your purchase of a spec.dock iPod solution for your vehicle. Audio connections may vary according to your particular setup. For any clarification on your particular vehicle, please email [info@2point5.com](mailto:info@2point5.com) or call 770-414-6038 with any further questions.

## spec.dock Audi A3 v.2 Installation Instructions



Begin by using your fingers to unsnap the trim around the shifter by pulling up on the front lip of this piece as shown.



Completely remove the shifter trim and set aside.



Using Audi radio removal keys, slide the radio out of the dash as shown. If the car is equipped with a navigation unit, note that the fourth key slides in behind the screen.



Using only your fingers, gently unsnap the trim around the hazard switch and storage pocket. Remove this piece completely and set aside.



Again using only your fingers, snap the climate control panel out of the dash as shown. It is not necessary to disconnect the connectors on the back of the climate control, as the wiring length allows it to easily move out of the way. Once this unit is removed, the radio can temporarily be slid back into the dash.



Use your fingers to apply pressure to the spots shown to unsnap the plastic trim at the back edge of the ashtray carrier.



Remove the two torx T-20 screws indicated here. This will allow the ashtray carrier to be lifted up and out of the console.



Make sure to disconnect the connector on the bottom side of the ashtray carrier so that it can be removed completely from the vehicle.



Place the ashtray carrier face-down on a soft surface and drill a small pilot hole in the location shown.



This hole will need to be opened up to 3/4" to allow the spec.dock's wiring to pass through.



Route the wiring from the spec.dock through the hole you just cut.



Remove the backing from the included double-sided tape and lower the spec.dock into position, pressing down firmly as shown.





When reinstalling the ashtray carrier with the spec.dock mounted back into the vehicle, route the cabling as shown above. This will make it very easy once the ashtray carrier is back in place to run the wiring up to the radio location where the interface electronics will be located.



Your spec.dock is now installed and can be connected to the interface electronics according to the instructions included. Make sure to test all functionality before completely reassembling the vehicle. Reassembly is the reverse of disassembly.