



Thank you for your purchase of a spec.dock iPod solution for your vehicle. Audio connections may vary according to your particular setup. 2point5 recommends having your spec.dock integrated by a certified professional installer. For any clarification on your particular vehicle, please email [info@2point5.com](mailto:info@2point5.com) or call 770-414-6038 with any further questions.

## **spec.dock BMW Z4 e85 v.2 Installation Instructions**



Begin by removing the ashtray lift tab from the ashtray carrier by snapping it out with your finger as shown.



Next, remove the single Torx T-20 screw located in the ashtray carrier's base.



Grasp the edge of the ashtray carrier and lift up. The carrier will begin to unsnap from the console itself.



As the ashtray carrier unsnaps. Lift the front edge up and toward you to clear the dash overhang. This piece will come completely free from the console and can be set aside with the electrical connectors still plugged into the switch panel.



Route the spec.dock's wiring through the ashtray carrier as shown and run to the appropriate location for connection to your vehicle's audio system (see interface instructions). At this point, you can begin to reinstall the ashtray carrier into the console. **Do not mount the spec.dock until this piece is reinstalled in the console.**



As you lower the ashtray carrier into its final position, make sure that the spec.dock's cable is routed as shown. This will prevent it from getting pinched between the ashtray carrier and any surrounding materials. Snap the ashtray carrier back in completely before proceeding to the next step.



The completed wiring portion should look like this. Note that the Torx screw is not reinstalled. It will be permanently left out, as the clips hold the ashtray carrier firmly in place, and reinstalling the screw would require removing the spec.dock each time vehicle service in this area needs to be performed





After cleaning the inside of the ashtray carrier with a high-quality degreaser such as denatured alcohol, remove the backing from the supplied double-sided tape that is attached to the spec.dock's base and lower the spec.dock into position while tucking any additional cabling into the openings between the ashtray carrier and the floor of the vehicle.



After dropping the spec.dock completely into position, press down firmly on the outer edges of the spec.dock to ensure proper adhesion of the double-sided tape. Verify all interface functions and enjoy!