In-vehicle Phone

Voice commands which are valid for all menus:

Cancel	Help / What can I say	Back	Head menu
Ends the voice control function.	By saying Help you can hear the commands, which are available in each submenu.	One step back.	The main menu is open.

The most important voice commands:

Head menu					
Dial Joe Bloggs	**Dial number**	**Contacts**	**Redial**	**Call lists**	**Messages**
Will not be displayed in the head menu. Direct call of a phonebook entry. If you have saved more than one number for one person, you can dial directly via the category, e.g. **„Dial Joe Bloggs home"** It is important to match the announced name exactly with the phone book entry.	▪ Digits (0..9) ▪ Dial ▪ Delete group ▪ Delete all ▪ Delete last ▪ Playback Special symbols like +, * and # can be actuated in the same way as the Pause function (space character) e. g. for mailbox functions.	▪ Select entry <digit> ▪ Playback ▪ Play list ▪ Select Joe Bloggs ▪ Dial ▪ Fast search ▪ Get details 　▪ Dial sim 　▪ Voicetag ▪ Next ▪ Previous ▪ Next Page ▪ Previous Page	Here, you can redial the telephone number which was most recently dialled with the BURY CP 1000 CarPhone.	▪ Dialled calls ▪ Received calls ▪ Missed calls In these menu items the following commands are available to you: ▪ Select entry <digit> ▪ Number ▪ Playback ▪ Dial ▪ Next ▪ Previous ▪ Next page ▪ Previous page	▪ All messages ▪ New messages In these menu items the following commands are available to you: ▪ Select entry <digit> ▪ Playback ▪ Dial ▪ Read ▪ Next ▪ Previous ▪ Next page ▪ Previous page

Read new message | Settings | Memo | Activate voice dial

Will not be displayed in the head menu. With this voice prompt you can directly reach a new message.

- Voice dial
- Magic word
- Advanced help on / off
- Audio feedback on / off
- Speaker adaptation
- Description

- Audio
- Ringtones
- Volume
- Mute delay

- Display
- Sleep mode
- Illumination
- Day/Night mode

- Phone
- Call answering
- Language
- PIN code
- Fixed dialling
- Short dial
- DSP
  - Enable / Disable DSP
- Number presentation
- GSM power off
- Date/Time
- System
- On-call duty

A voice memo can be saved directly from the main menu or during a telephone call.

If the Magic Word function is activated, you can start the voice control by this command.

Mini USB

Display 2,8"

SOS Button

Right Menu Button

End Button

Volume control

4 Way Navigation Key Scroll through menus and lists

Left Menu Button

Start Call / Redial Button

SIM Card slot

Keypad – Large illuminated, well-spaced, tactile buttons ensure accuracy and speed

Voice control activation button