



The steering wheel buttons perform the following functions (if supported by the radio) :

- 1- Volume +
- 2- Volume -
- 3- Accept incoming call
- 4- Reject incoming call
- 5- Mute
- 6- Source
- 7- Seek up
- 8- Seek down

Steering wheel control interface installation kit for:

# FIAT, CITROEN, PEUGEOT

Model: Ducato III 250/251 2006-2011  
Ducato III 250/251 2011-2014  
Ducato III 250/251 2014 >  
Jumper 2015 >  
Boxer II 250/251 2006 >


Kit content: SWC resistive interface-wiring harness-radio adapter  
Compatibility: Compatible with Open-dash version



## INSTALLATION MANUAL

All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
12/2019 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.


All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
12/2019 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.



**ATTENTION!**

In order to prevent ESD damage, the WHEEL REMOTE JACK (2) must be connected before plugging in the connectors on car side.

- 1- to Alpine Head Unit
- 2- to WIRED REMOTE SOCKET (NOTE: do not connect to microphone socket)
- 3- to CAR CONNECTOR
- 4- to CAMERA CONTROL/REMOTE
- 5- Green/White - SPEED (Connect to the Alpine Head Unit)
- 6- Orange/White - REVERSE & Green/White -SPEED (Connect as shown in the picture below)



Position of fuse box and the two terminals for speed and reverse connection.




Routing of the speed & reverse cable



01 Disconnect the two lower 60-pin connectors.


REVERSE      SPEED SIGNAL



01 Left Connector (green):  
Pin 4 = Reverse Light  
Right Connector (black):  
Pin 56 = Speed Signal

02 The white / blue cable carries the reverse signal. Remove the terminal from the connector housing.


02 Pull the blue / white cable out of the plug housing.



03 Use the supplied Y-cable of the main cable harness.

03 Insert the Y-cable contact into the connector housing (Pin 4). The latch must point outward.

03 Connect the Y-cable's housing to the connector of reverse signal.



04 Remove the black connector cover on the same principle as the green connector and plug the speed signal cable into the free chamber 56.

Route the two cables (Speed/Reverse) along the fuse box.

Run the cables behind the dashboard up to the radio dock and fix it in appropriate places with cable ties.

cut along the dotted line - copy for the vehicle owner