

ZDAPVW1



1x ZDA4.6



1x SOT Cable



1x ZDAISOT



2x Release keys


Installation Tools Required

Vehicle used for installation:*

Volkswagen Passat 2020 (B8)
Standard Stereo

**Some differences may occur between different car and year models.*

Plastic Pry Tool



PHOENIX GOLD

ZDAPVW1 Installation 1

Tools required:



2x Release Keys

1. Open the glove box



2. Locate the factory stereo



3. Insert the release keys



4. Pull out the stereo



ZDAPVW1 Installation 2

Tools required:



1x SOT Cable



1x ZDAISOT

5. Unplug the quadlock connector




6. Connect the SOT cable



7. Connect the SOT to the stereo



8. Connect ZDAISOT to SOT cable



ZDAPVW1 Installation 3

Tools required:




1x Plastic Pry Tool

9. Open the side of the glove box




10. Pull ZDAISOT out



11. Pull up the side panel



12. Pull out plastic panel




ZDAPVW1 Installation 4

Tools required:

13. Pull panel towards you




14. Route the cable behind the panels



15. Pull up the carpet



16. Route the cable under the carpet



ZDAPVW1 Installation 5

Tools required:



1x ZDA4.6



1x Computer

17. Install the ZDA4.6



18. Physical install is now complete



19. Go to phoenixgold-eu.com/downloads/ and download the ZDA4.6 software and your Phoenix Gold sound curve

The screenshot shows the ZDA4.6 software interface. At the top left is a frequency response graph with a green line labeled "All Bypass" and a red point at 8000Hz, 2.515Q, 0.0dB. Below the graph is a table of 10 EQ bands:

ID	1	2	3	4	5	6	7	8	9	10
F:	31	65	125	250	500	1000	2000	4000	8000	16000
Q:	2.515	2.515	2.515	2.515	2.515	2.515	2.515	2.515	2.515	2.515
G:	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Below the EQ table are volume sliders for six channels (CH1-CH6) and a "VOLUME" section. On the right, there are HPF and LPF settings, a car diagram, and buttons for "EQ RESET", "PEQ Mode", "System", "Program", "Reset Output", and "Link Output". The "ON Line" button is highlighted in green.


Software Installation 1

Tools required:




1x Computer


20. Press "Program"



21. Press "Load PC Presets File"



22. Go to your saved location and choose your Phoenix Gold sound curve, then click "Open"



Software Installation 2

Tools required:



1x Computer

23. Press "Program"

The screenshot shows the Phoenix Gold software interface. The top left features a frequency response graph with a red line and a peak at 8000Hz. The top right shows a car audio system diagram with speaker levels. The middle section contains various EQ and filter controls, including HPF and LPF settings. The bottom section has volume sliders for channels CH4, CH5, and CH6. A red circle highlights the 'Program' button in the bottom right area.

24. Press "Save As Machine Preset"

The screenshot shows the Phoenix Gold software interface with a context menu open over the 'PEQ Mode' button. The menu options are: Load Machine Preset(L), Save As Machine Preset(I), Delete Machine Preset(D), Load PC Presets File(O), Save As PC Presets File(S), Load All Presets, and Save All Presets. A red arrow points to the 'Save As Machine Preset(I)' option.

25. Press "Save"

The screenshot shows the Phoenix Gold software interface with a 'Save As Machine Preset' dialog box open. The dialog box has a table with columns 'No.' and 'Preset'. The 'Save' button is highlighted with a red arrow.

No.	Preset
1	
2	
3	
4	
5	
6	


Software Installation 3

Tools required:



1x Computer

26. Press "OK". The sound curve is now installed and saved to the ZDA4.6.



On Behalf of the Phoenix Gold team,
Thank you for choosing us!

Your installation is complete and we hope that your new upgraded system will bring you joy and happiness for many years to come when listening to your favorite music. As always, our goal is bringing you The Gold Standard in Sound.



www.phoenixgold-eu.com